Lab 4: Role-based security

The Microsoft .NET environment now offers an excellent alternative to Java in producing portable and secure code. It uses a role-based approach for user authentication, with the **WindowsIndentity** class, where the GetCurrent() method can be used to get the current user. The **WindowsPrincipal** class can then be used to apply the role. For example to test if the user is an administrator:

```
using System;
using System.Security;
using System. Security. Principal;
namespace ConsoleApplication3
  class Class1
     static void Main(string[] args)
       WindowsIdentity myID = WindowsIdentity.GetCurrent();
        System.Console.WriteLine("Your ID: " + myID.Name);
        System.Console.WriteLine("Authentication: " +
                                            myID.AuthenticationType);
       WindowsPrincipal myPrin = new WindowsPrincipal(myID);
       if (myPrin.IsInRole(WindowsBuiltInRole.Administrator))
          System.Console.WriteLine("You're an Administrator ");
        else
          System.Console.WriteLine("You're not an Administrator");
       Console.ReadLine();
     }
  }
```

A sample run gives:

```
Your ID: BILLS\William Buchanan
Authentication: NTLM
You're an Administrator
```

Other roles are also defined, such as:

```
WindowsBuiltInRole.Guest
WindowsBuiltInRole.PowerUser
WindowsBuiltInRole.User
```

Next we could apply this security to only allow an administrator to view the IP address of the computer, with:

```
using System;
using System.Security;
using System.Security.Principal;
using System.Net;
```

```
namespace ConsoleApplication3
  class Class1
     static void Main(string[] args)
       WindowsIdentity myID = WindowsIdentity.GetCurrent();
        System.Console.WriteLine("Your ID: " + myID.Name);
       System.Console.WriteLine("Authentication: " +
                                             myID.AuthenticationType);
       WindowsPrincipal myPrin = new WindowsPrincipal(myID);
        if (myPrin.IsInRole(WindowsBuiltInRole.Administrator))
          string strHostName = Dns.GetHostName();
          IPHostEntry ipEntry = Dns.GetHostByName(strHostName);
          IPAddress [] addr = ipEntry.AddressList;
           System.Console.WriteLine("IP: " + addr[0]);
       else
          System.Console.WriteLine(
                  "Sorry \dots you have no permissions for this");
  }
```

Run this program, and view the output.